


BRAKE PEDAL

No.	Part No.	Description	Year
1	24B7-K	Pin kit: Clevis, incl #2 & 3, (3)	24-53
2	922007-AN	Washer: AN, s/s (3), 5/pk	24-53
3	636104	Pin: Cotter (3), 5/pk	24-53
4	24B6	Clevis: Brake rod (3)	24-53
5	606010	Nut: 5/16-24, s/s (3), 5/pk	24-53
6	75582	Rod: Brake, rear, chrome	40-53
7	42460	Cover: Stop light switch	40-53
8	42460	Strap: Stop light switch cover	40-53
9	41363	Switch: Stop light	38-53
9	40526	Switch: Stop light	36-37
10	42581	Spring: Stop light switch	38-53
11	45076	Pivot bolt: Brake bell crank	40-53
12	922009	Lock Washer, bellcrank bolt, 7/16, s/s, 5pk	40-53
13	605014	Nut: Jam, bellcrank bolt, 7/16-20, s/s, 5pk	40-53
14	42466	Bell crank: Brake rod	40-53
15	416002	Fitting: Grease, straight (2)	40-53
16	42497	Clip: Brake pedal return spring	40-53
17	606018	Nut: Brake pedal, incl with #19, s/s	40-53



No.	Part No.	Description	Year
18	922011	Washer: Lock, 9/16, incl with #19, s/s	40-53
19	45071-K	Bolt kit: Brake pedal, incl #17 & 18, s/s	40-53
20	74086	Pedal: Brake	32-39
20	75608	Pedal: Brake	40-53
21	42481	Spacer: Brake pedal	40-53
22	540022	Pedal pad set: Brake/clutch, set of 3 w/Indian script	32-53
23	42587	Rod: Brake, front, chrome	40-53
23	38440	Rod: Brake, cad	32-39
24	37741	Pin: Bell crank to clevis, special	40-53
25	38331	Spring: Brake return	40-53
26	754405	Screw: 10-32 x 3/8 RHMS, incl w/#7, s/s (2), 5/pk	40-53
27	922004	Washer: Lock, #10, incl w/#7 (2), 5/pk	40-53
28	35C422	Lever: Rear brake	31-39
29	42461	Lever: Rear brake	40-42
30	50228	Lever: Rear brake	44-53
31	922006	Lock Washer, 5/16, s/s 5/pk	44-53
32	254012	Bolt: Pinch, 1/4-28 x 7/8, s/s 5/pk	44-53

BRAKE PEDAL

