


CLUTCH PEDAL

No.	Part No.	Description	Year
1	636108	Pin: Cotter, clutch pedal nut, 3/32"x1", 5/pk	32-53
2	603016	Nut: Castle, clutch pedal, 1/2"-20	32-53
3	20B313	Spring: Tension, clutch pedal	22-53
4	416002	Fitting: Grease, straight	22-53
5	28B58	Plate: Clutch pedal steel	32-53
6	20B312	Disc: Friction, clutch pedal	22-53
7	636104	Pin: Cotter, incl with #9, 5/pk	24-53
8	920007-AN	Washer: AN, s/s, incl with #9, 5/pk	24-53
9	24B7K	Pin kit: Clevis, includes: #7 pin and #8 washer	24-53
10	24B6	Clevis: Clutch rod	24-53

No.	Part No.	Description	Year
11	606010	Nut: 5/16-24, s/s, 5/pk	24-53
12	40029	Rod: Clutch release	35-39
12	42588	Rod: Clutch release, chrome	40-53
13	75631-P	Pin: Clutch heel plate	32-53
14	24B79	Spring: Clutch heel plate	24-53
15	75631-H	Heel plate: Clutch	32-53
16	540022	Pedal pad set: Brake/clutch, set of 3 w/Indian script	32-53
17	74092	Pedal: Clutch	32-39
17	75631	Pedal: Clutch	40-51
17	633003	Pedal: Clutch	52-53



CLUTCH PEDAL

